



NOTES:

1. USE #2 TYPE B THREAD FORMING SCREW TO MOUNT PCB.

PACNTEC
1-610-361-4231

FXT-1632
FXTA-1632

VISIT **PACNTEC**
ON THE WORLD WIDE WEB
www.pactecenclosures.com

COLOR / MATERIAL CODE	
COLOR	94HB 94V0
BLACK	000 028
P.C. BONE	039 060

INSERT AREAS ARE SECTIONS IN OUT TOOLS THAT CAN BE REMOVED AND REPLACED WITH CUSTOMER SPECIFIC DETAILS

DRAWING NUMBER	REV
87175	02